

# QWIZDOM Q5 REMOTE

**Send:** Press to submit answer, select a menu option, and confirm session or user ID.

**Battery Power:**  
Indicates battery charge.

**Q#:** Displays the current question number.

**Power:** Slide to turn on/off.

**Light:** Press to turn on backlight.

**Clear:** Press to delete the last character or change answer.



**Thumb pad:**  
Press to navigate between menu choices and letters in word input questions.

**R#:** Displays the remote number.

**Question:** Press to request help during a presentation.

**Menu:** Press to view menu options:  
*Search Again, Enter Session ID, and Exit Menu.*

Qwizdom Inc © 2009

## Common Remote LCD Displays

Finding Host	Remote is searching for the host.
Remote #	Remote has found the host and is ready for a question slide.
PressKey	Remote is idle. Press any key, except "Menu," to reactivate.
LowBatt	Batteries need to be recharged.
Not Active	Remote senses the host is not in use. If remote remains not active after starting a presentation, press "Send."
Not Found	Remote cannot find the host. Reenter the "Session ID." Press "Menu" and use the thumb pad to scroll to "Session ID." Reenter the session ID and press "Send." If "No Net" continues, reenter "User ID" and "Session ID."
Access Denied	User denied due to incorrect Session ID, User ID, or a duplicate ID.
Loading	Loading an answer key; may take a few moments.
ActivityID	Requesting an Answer Key activity number. Prompt only appears when multiple test versions are being presented. Activity numbers should be noted on the test sheets before presenting; numbers cannot be viewed while in presentation mode.